



# mPower<sup>™</sup> PRO

*6-Port mFi Power Strip  
with Ethernet and Wi-Fi*

Model: mPower PRO (EU)



QUICK START GUIDE



## Introduction

Thank you for purchasing the Ubiquiti Networks™ mFi™ mPower™ PRO (EU). The mPower PRO (EU) is a power strip with Ethernet and Wi-Fi capability designed for use with the Ubiquiti mFi platform. Once connected, you can use the mFi Controller software to monitor your devices and define automation rules using your web browser. This Quick Start Guide is designed to guide you through the installation and also includes the Warranty terms.

## Package Contents



mPower PRO (EU)

Mounting  
PlateScrews  
(Qty. 2)Anchors  
(Qty. 2)Quick Start  
Guide

## Cloud Support


The mFi Controller software can be installed on a local system or run from the cloud at **mfi.ubnt.com**. Using the cloud allows you access from anywhere with an Internet connection.

## System Requirements

- Microsoft Windows XP, Windows Vista, Windows 7, Windows 8, or Mac OS X
- Java Runtime Environment 1.6 (or above)
- Web Browser: Mozilla Firefox, Google Chrome, or Microsoft Internet Explorer 8 (or above)

## Hardware Overview

### Top



### Front



**Status LED** The *Status* LED primary states are listed below:



**Solid yellow** When first powered on in factory default mode.



- **Flashing blue** Connecting to mFi Cloud or Controller.
- **Solid blue** Successfully connected to mFi Cloud or Controller.

**Device Reset Button** The *Device Reset* button serves two functions:

- **Restart** Restarts the device when you press and release it quickly.
- **Restore Factory Defaults** Press and hold until the LED alternates colors and then remains steady yellow to restore the device to the factory default settings.

**Ethernet Port** Used to connect to an Ethernet network and also configuration of Controller and Wi-Fi settings.


**Circuit Breaker Reset Button** When excessive current triggers the circuit breaker, the outlets will shut off. Press this button to reset the circuit breaker.

## Hardware Installation

1. Connect the mPower PRO (EU) to a power outlet.




2. Connect an Ethernet cable to the *Ethernet* port on the mPower PRO (EU).



The mPower PRO (EU) can be connected to your network using one of two methods:

- **Ethernet** The mPower PRO (EU) is DHCP-enabled. Connect the Ethernet cable from the mPower PRO (EU) to your LAN.



- **Wi-Fi** The mPower PRO can connect to a wireless network once Wi-Fi settings have been configured using the Ethernet connection. For instructions, refer to *Accessing the Configuration Portal* on page 14.


## Wall-Mount

The mPower PRO (EU) includes an optional mounting plate.

1. Position the *Mounting Plate* on the wall with the text in the proper orientation, and mark the mounting holes on the wall.



2. Use a 6 mm drill bit to drill the holes.
3. Insert the anchors into the holes and use a Phillips screwdriver to secure *Screws* through the *Mounting Plate* into the *Anchors*.





4. Align the back of the mPower PRO (EU) with the *Mounting Plate*. Slide the mPower PRO (EU) to the right to lock it into place.



## Software Download and Installation

For local mFi Controller installations, the mFi Controller software is installed just once when you initially create a mFi network. It is not necessary to go through the software installation process every time you add another mFi device.




**Note:** If you are using the cloud, there is no need to install the mFi Controller software locally. Skip to *Accessing the Configuration Portal* on page 14.

The mFi Controller software can be downloaded from the Ubiquiti Networks website.


1. Go to **[downloads.ubnt.com/mfi](https://downloads.ubnt.com/mfi)**
2. Mac users should download **mFi.dmg** and Windows users should download **mFi-installer.exe**.
3. Follow the instructions for your computer type.

## Mac Users


1. Click the **Install** icon.



2. Click **Continue** and follow the on-screen instructions to install the software.




3. Go to **Go > Applications** and double-click the **mFi** icon.




Proceed to *Configuring the mFi Controller Software* on page 11.

## PC Users


1. Launch **mFi-installer.exe**.
2. Click **Install**.



3. If your computer doesn't have Java 1.6 or above installed, you will be prompted to install it. Click **Install** to continue.




4. Ensure the *Start mFi Controller after installation* option is checked and click **Finish**.





**Note:** The mFi Controller software can also be launched from **Start > All Programs**.




## Configuring the mFi Controller Software

1. The mFi Controller software startup will begin. Click **Launch a Browser to Manage the Network**.




2. The *mFi Configuration Wizard* will appear the first time you launch the mFi Controller software. On the *Welcome* screen, select your language and country. Click **Next**.



3. Select the device(s) that you want to configure. The *Refresh* button can be used to refresh the list of devices. Click **Next** to continue.




4. Enter an administrator name in the *Admin Name* field. Enter a password in the *Password* and *Confirm* fields. Click **Next**.



The screenshot shows the mFi installation wizard interface. At the top left is the mFi logo. A progress bar at the top has four steps: 'welcome', 'discover', 'password', and 'finish'. The 'password' step is currently active, indicated by a blue line and a blue arrow pointing to it. Below the progress bar, the text reads: 'Please enter an administrator name and password for mFi Controller access.' There are three input fields: 'Admin Name', 'Password', and 'Confirm'. The 'Admin Name' field contains a vertical cursor. At the bottom right, there are two buttons: 'Back' (grey) and 'Next' (green).

5. Click **Finish** to confirm your settings.



The screenshot shows the mFi installation wizard interface at the 'finish' step. The progress bar at the top has four steps: 'welcome', 'discover', 'password', and 'finish'. The 'finish' step is currently active, indicated by a blue line and a blue arrow pointing to it. Below the progress bar, the text reads: 'Please review the settings below. Click Back to make any changes or Finish to activate the settings. Once finished you will be redirected to the management interface.' Below this text, the text reads: 'Admin Name ubnt'. At the bottom right, there are two buttons: 'Back' (grey) and 'Finish' (green).

6. A login screen will appear for the mFi Controller management interface. Enter the *Admin Name* and *Password* that you created and click **Login**.



## Accessing the Configuration Portal

You need to connect to the Configuration Portal to configure any of the following:

- Cloud access
- Access to local mFi Controller on a different IP network
- Wireless network access (Wi-Fi settings)



**Note:** If you are not using these configurations, you do not need to access the Configuration Portal.


The Configuration Portal can be accessed in two ways:

- Connect an Ethernet cable directly from your computer to the *Ethernet Port* on the mPower PRO (EU) and configure your computer with a static IP address.
- Connect an Ethernet cable from your DHCP-enabled LAN to the *Ethernet Port* on the mPower PRO (EU).



## Configuration Portal via Ethernet to Computer

1. Make sure that your computer is directly connected via Ethernet to the *Ethernet Port* on the mPower PRO (EU).




2. Configure the Ethernet adapter on your computer with a static IP address on the 192.168.1.x subnet.
3. Launch your web browser and type **http://192.168.1.20** in the address field. Press **enter** (PC) or **return** (Mac).




4. Go to *Configuration Portal Interface Settings* on page 17.

## Configuration Portal via LAN with DHCP



If it is not already installed, download the Ubiquiti Device Discovery Tool (v2.3) at [www.ubnt.com/download#app](http://www.ubnt.com/download#app)


1. Launch the *Ubiquiti Device Discovery Tool*.
2. A list of Ubiquiti devices on the network will appear. Locate the appropriate device (named P6E) under *Product Name* and double-click it.





**Note:** If you have more than one of the same device model, you can determine which one you are selecting by checking the Hardware (MAC) Address on the device label.

3. Click **WEB UI** on the right.



## Configuration Portal Interface Settings


1. The login screen will appear. Enter **ubnt** in the *Username* and *Password* fields.



- The *Main* tab of the *Configuration Portal* will appear. Click the **Configuration** tab.



- Enter your configuration information on the *Configuration* tab:



**mFi Controller** Select the mFi Controller from the drop-down and enter the Controller information:

- **Cloud** Enter the email and password used to register at *mfi.ubnt.com*.

The image shows a configuration window titled "mFi Controller". It features a dropdown menu labeled "Controller" with "Cloud" selected. Below this are two empty text input fields labeled "Email" and "Password".

- **Local** Enter the following settings:
  - **Address** The IP address and http port used by the Controller. (The port is usually 6080, for example: 1.1.1.1:6080 or mfi.acme.com:6080).
  - **User** The user name defined during the mFi Configuration Wizard.
  - **Password** The password defined during the mFi Configuration Wizard.

The image shows a configuration window titled "mFi Controller". It features a dropdown menu labeled "Controller" with "Local" selected. Below this are three text input fields: "Address" (with a placeholder "example: 1.1.1.1:6080"), "User", and "Password".

**Wireless Settings** To use the mPower PRO on a Wi-Fi network, configure the *Wireless Settings*:

The image shows a configuration window titled "Wireless Settings". It contains several fields and options:
 

- SSID: [text input] [Scan... button]
- Security: none [dropdown]
- Authentication Type:  Open  Shared Key
- WEP Key Length: 64 bit [dropdown]
- WEP Key: [text input]
- WPA Authentication: PSK [dropdown] EAP-TTLS [dropdown] MSCHAPV2 [dropdown]
- WPA Preshared Key: [text input]
- WPA Identity: [text input]
- WPA User Name: [text input]
- WPA User Password: [text input]
- Key Type: HEX [dropdown]
- Key Index: 1 [dropdown]

- a. Click **Scan** for a list of available SSIDs and select the appropriate SSID or type in the name manually in the *SSID* field.
- b. Select the appropriate *Security* and *Authentication* settings for your network.
- c. Enter your network key.

After you've entered the necessary settings, click **Change**. You will be asked to apply the changes; click **Apply**.

4. Click the **Main** tab. The Controller and WLAN status should be displayed confirming your connection. Click the **Refresh** button, if necessary.

The screenshot shows the mPower PRO web interface. At the top, there are tabs for 'Main' and 'Configuration', and a 'Logout' button. The 'Status' section is active, displaying the following information:

Device Info		Controller Status	
Device Name:	mFi	Controller:	Connected
Wireless Mode:	802.11n	IPV4-ADD:	192.168.0.10
SSID:	WLAN-00	Signal Strength:	40 dBm
Security:	WPA2-TKIP	Noise Floor:	-84 dBm
Version:	1.0.0	Transmit CQD:	0.1 %
Uptime:	10:21:47	TX/RX Rate:	342/1000 110.0 Mbps
Date:	2010-09-09 09:44:23	WLAN IP Address:	192.168.0.10
Channel/Frequency:	1 (2412 MHz)	LAN IP Address:	0.0.0.0
APN/Default:	04 (3.1 mSec @ 1 km)	WLAN-MAC:	00:0F:00:0E:F4:3F
Tx/Rx Chain:	0/0	LAN-MAC:	00:0F:00:0E:F4:3F
		LAN:	192.168.0.10

Below the status information, there are two graphs under the 'Monitor' section:


- WLAN:** A line graph showing 'Tx Rate' (blue) and 'Rx Rate' (red) over time. The y-axis ranges from 0 to 100. Both rates are currently near 0.
- WLAN:** A line graph showing 'Tx Pkts/s' (blue) and 'Rx Pkts/s' (red) over time. The y-axis ranges from 0 to 10. Both rates are currently near 0.


At the bottom of the interface, there is a copyright notice: © Copyright 2008-2010 Ubiquiti Networks.




**Note:** If the status doesn't appear to be connected after several refresh attempts, go back to the *Configuration* page and enter your settings again.

## 5. Log in to the mFi Controller.



6. The mPower PRO appears with the mPower  icon in the left panel under the *Drag on to Map* heading. Once you've customized your map, you can position the mPower PRO in the appropriate location.



For additional details on the mFi Controller software, please refer to the mFi User Guide available on our website at: **[documentation.ubnt.com/mfi](http://documentation.ubnt.com/mfi)**

## Specifications

mPower PRO (EU)	
Dimensions	250.37 x 116.7 x 49 mm
Weight	754.4 g
Mounting	Wall (Kit Included)
Power	220-250VAC, 50 Hz, 16 A Per Outlet, 16 A Total
Outlets	6
Networking Interface	(1) 10/100 Ethernet Port
Wi-Fi Standards	802.11b/g/n
Memory	16 MB RAM, 8 MB Flash
LEDs	1 LED (Status)
Operating Temperature	0 to 40° C
Operating Humidity	10-90% Noncondensing



## Safety Notices

1. Read, follow, and keep these instructions.
2. Heed all warnings.
3. Only use attachments/accessories specified by the manufacturer.



**WARNING:** Use only in a dry location.



**WARNING:** Do not plug in to another relocatable power tap.



**WARNING:** To reduce the risk of electric shock, use only indoors.



**WARNING:** Do not operate when covered.



**WARNING:** Power is dead only when unplugged.

## German Safety Notices



**WARNUNG:** Nicht hintereinander stecken.



**WARNUNG:** Nicht abgedeckt betreiben.



**WARNUNG:** Spannungsfrei nur bei gezogenem Stecker.

## Limited Warranty

UBIQUITI NETWORKS, Inc (“UBIQUITI NETWORKS”) warrants that the product(s) furnished hereunder (the “Product(s)”) shall be free from defects in material and workmanship for a period of one (1) year from the date of shipment by UBIQUITI NETWORKS under normal use and operation. UBIQUITI NETWORKS’ sole and exclusive obligation and liability under the foregoing warranty shall be for UBIQUITI NETWORKS, at its discretion, to repair or replace any Product that fails to conform to the above warranty during the above warranty period. The expense of removal and reinstallation of any Product is not included in this warranty. The warranty period of any repaired or replaced Product shall not extend beyond its original term.

## Warranty Conditions

The above warranty does not apply if the Product:

- (I) has been modified and/or altered, or an addition made thereto, except by Ubiquiti Networks, or Ubiquiti Networks’ authorized representatives, or as approved by Ubiquiti Networks in writing;
- (II) has been painted, rebranded or physically modified in any way;
- (III) has been damaged due to errors or defects in cabling;
- (IV) has been subjected to misuse, abuse, negligence, abnormal physical, electromagnetic or electrical stress, including lightning strikes, or accident;
- (V) has been damaged or impaired as a result of using third party firmware; or
- (VI) has no original Ubiquiti MAC label, or is missing any other original Ubiquiti label(s).

In addition, the above warranty shall apply only if: the product has been properly installed and used at all times in accordance, and in all material respects, with the applicable Product documentation; all Ethernet cabling runs use CAT5 (or above), and for outdoor installations, shielded Ethernet cabling is used, and for indoor installations, indoor cabling requirements are followed.

## Returns

No Products will be accepted for replacement or repair without obtaining a Return Materials Authorization (RMA) number from UBIQUITI NETWORKS during the warranty period, and the Products being received at UBIQUITI NETWORKS' facility freight prepaid in accordance with the RMA process of UBIQUITI NETWORKS. Products returned without an RMA number will not be processed and will be returned freight collect or subject to disposal. Information on the RMA process and obtaining an RMA number can be found at: **[www.ubnt.com/support/warranty](http://www.ubnt.com/support/warranty)**.

## Disclaimer

EXCEPT FOR ANY EXPRESS WARRANTIES PROVIDED HEREIN, UBIQUITI NETWORKS, ITS AFFILIATES, AND ITS AND THEIR THIRD PARTY DATA, SERVICE, SOFTWARE AND HARDWARE PROVIDERS HEREBY DISCLAIM AND MAKE NO OTHER REPRESENTATION OR WARRANTY OF ANY KIND, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, REPRESENTATIONS, GUARANTEES, OR WARRANTIES OF MERCHANTABILITY, ACCURACY, QUALITY OF SERVICE OR RESULTS, AVAILABILITY, SATISFACTORY QUALITY, LACK OF VIRUSES, QUIET ENJOYMENT, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT AND ANY WARRANTIES ARISING FROM ANY COURSE OF DEALING, USAGE OR TRADE PRACTICE IN CONNECTION WITH SUCH PRODUCTS AND SERVICES. BUYER ACKNOWLEDGES THAT NEITHER UBIQUITI NETWORKS NOR ITS THIRD PARTY PROVIDERS CONTROL BUYER'S EQUIPMENT OR THE TRANSFER OF DATA OVER COMMUNICATIONS FACILITIES, INCLUDING THE INTERNET, AND THAT THE PRODUCTS AND SERVICES MAY BE SUBJECT TO LIMITATIONS, INTERRUPTIONS, DELAYS, CANCELLATIONS AND OTHER PROBLEMS INHERENT IN THE USE OF COMMUNICATIONS FACILITIES. UBIQUITI NETWORKS, ITS AFFILIATES AND ITS AND THEIR THIRD PARTY PROVIDERS ARE NOT RESPONSIBLE FOR ANY INTERRUPTIONS, DELAYS, CANCELLATIONS, DELIVERY FAILURES, DATA LOSS, CONTENT CORRUPTION, PACKET LOSS, OR OTHER DAMAGE RESULTING FROM ANY OF THE FOREGOING. In addition, UBIQUITI NETWORKS does not warrant that the operation of the Products will be error-free or that operation will be uninterrupted. In no event shall UBIQUITI NETWORKS be responsible for damages or claims of any nature or description relating to system performance, including coverage, buyer's selection of products (including the Products) for buyer's application and/or failure of products (including the Products) to meet government or regulatory requirements.

## Limitation of Liability

EXCEPT TO THE EXTENT PROHIBITED BY LOCAL LAW, IN NO EVENT WILL UBIQUITI OR ITS SUBSIDIARIES, AFFILIATES OR SUPPLIERS BE LIABLE FOR DIRECT, SPECIAL, INCIDENTAL, CONSEQUENTIAL OR OTHER DAMAGES (INCLUDING LOST PROFIT, LOST DATA, OR DOWNTIME COSTS), ARISING OUT OF THE USE, INABILITY TO USE, OR THE RESULTS OF USE OF THE PRODUCT, WHETHER BASED IN WARRANTY, CONTRACT, TORT OR OTHER LEGAL THEORY, AND WHETHER OR NOT ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

### Note

Some countries, states and provinces do not allow exclusions of implied warranties or conditions, so the above exclusion may not apply to you. You may have other rights that vary from country to country, state to state, or province to province. Some countries, states and provinces do not allow the exclusion or limitation of liability for incidental or consequential damages, so the above limitation may not apply to you. EXCEPT TO THE EXTENT ALLOWED BY LOCAL LAW, THESE WARRANTY TERMS DO NOT EXCLUDE, RESTRICT OR MODIFY, AND ARE IN ADDITION TO, THE MANDATORY STATUTORY RIGHTS APPLICABLE TO THE LICENSE OF ANY SOFTWARE (EMBEDDED IN THE PRODUCT) TO YOU. The United Nations Convention on Contracts for the International Sale of Goods shall not apply to any transactions regarding the sale of the Products.

## Compliance

### CE Marking

CE marking on this product represents the product is in compliance with all directives that are applicable to it.



## RoHS/WEEE Compliance Statement



### English

European Directive 2002/96/EC requires that the equipment bearing this symbol on the product and/or its packaging must not be disposed of with unsorted municipal waste. The symbol indicates that this product should be disposed of separately from regular household waste streams. It is your responsibility to dispose of this and other electric and electronic equipment via designated collection facilities appointed by the government or local authorities. Correct disposal and recycling will help prevent potential negative consequences to the environment and human health. For more detailed information about the disposal of your old equipment, please contact your local authorities, waste disposal service, or the shop where you purchased the product.

### Deutsch

Die Europäische Richtlinie 2002/96/EC verlangt, dass technische Ausrüstung, die direkt am Gerät und/oder an der Verpackung mit diesem Symbol versehen ist, nicht zusammen mit unsortiertem Gemeindeabfall entsorgt werden darf. Das Symbol weist darauf hin, dass das Produkt von regulärem Haushaltsmüll getrennt entsorgt werden sollte. Es liegt in Ihrer Verantwortung, dieses Gerät und andere elektrische und elektronische Geräte über die dafür zuständigen und von der Regierung oder örtlichen Behörden dazu bestimmten Sammelstellen zu entsorgen. Ordnungsgemäßes Entsorgen und Recyceln trägt dazu bei, potentielle negative Folgen für Umwelt und die menschliche Gesundheit zu vermeiden. Wenn Sie weitere Informationen zur Entsorgung Ihrer Altgeräte benötigen, wenden Sie sich bitte an die örtlichen Behörden oder städtischen Entsorgungsdienste oder an den Händler, bei dem Sie das Produkt erworben haben.

## Español

La Directiva 2002/96/CE de la UE exige que los equipos que lleven este símbolo en el propio aparato y/o en su embalaje no deben eliminarse junto con otros residuos urbanos no seleccionados. El símbolo indica que el producto en cuestión debe separarse de los residuos domésticos convencionales con vistas a su eliminación. Es responsabilidad suya desechar este y cualesquiera otros aparatos eléctricos y electrónicos a través de los puntos de recogida que ponen a su disposición el gobierno y las autoridades locales. Al desechar y reciclar correctamente estos aparatos estará contribuyendo a evitar posibles consecuencias negativas para el medio ambiente y la salud de las personas. Si desea obtener información más detallada sobre la eliminación segura de su aparato usado, consulte a las autoridades locales, al servicio de recogida y eliminación de residuos de su zona o pregunte en la tienda donde adquirió el producto.

## Français

La directive européenne 2002/96/CE exige que l'équipement sur lequel est apposé ce symbole sur le produit et/ou son emballage ne soit pas jeté avec les autres ordures ménagères. Ce symbole indique que le produit doit être éliminé dans un circuit distinct de celui pour les déchets des ménages. Il est de votre responsabilité de jeter ce matériel ainsi que tout autre matériel électrique ou électronique par les moyens de collecte indiqués par le gouvernement et les pouvoirs publics des collectivités territoriales. L'élimination et le recyclage en bonne et due forme ont pour but de lutter contre l'impact néfaste potentiel de ce type de produits sur l'environnement et la santé publique. Pour plus d'informations sur le mode d'élimination de votre ancien équipement, veuillez prendre contact avec les pouvoirs publics locaux, le service de traitement des déchets, ou l'endroit où vous avez acheté le produit.

## Italiano

La direttiva europea 2002/96/EC richiede che le apparecchiature contrassegnate con questo simbolo sul prodotto e/o sull'imballaggio non siano smaltite insieme ai rifiuti urbani non differenziati. Il simbolo indica che questo prodotto non deve essere smaltito insieme ai normali rifiuti domestici. È responsabilità del proprietario smaltire sia questi prodotti sia le altre apparecchiature elettriche

ed elettroniche mediante le specifiche strutture di raccolta indicate dal governo o dagli enti pubblici locali. Il corretto smaltimento ed il riciclaggio aiuteranno a prevenire conseguenze potenzialmente negative per l'ambiente e per la salute dell'essere umano. Per ricevere informazioni più dettagliate circa lo smaltimento delle vecchie apparecchiature in Vostro possesso, Vi invitiamo a contattare gli enti pubblici di competenza, il servizio di smaltimento rifiuti o il negozio nel quale avete acquistato il prodotto.

## Declaration of Conformity

**Česky [Czech]** UBIQUITI NETWORKS tímto prohlašuje, a tento UBIQUITI NETWORKS device, je ve shodě se základními požadavky a dále splňuje podmínky ustanovenými směrnicí 1999/5/ES.

**Dansk [Danish]** Undertegnede UBIQUITI NETWORKS erklærer herved, at følgende udstyr UBIQUITI NETWORKS device, overholder de væsentlige krav og øvrige relevante krav i direktiv 1999/5/EF.

**Nederlands [Dutch]** Hierbij verklaart UBIQUITI NETWORKS dat het toestel UBIQUITI NETWORKS device, in overeenstemming is met de essentiële eisen en de andere relevante bepalingen van richtlijn 1999/5/EG.

Bij deze verklaart UBIQUITI NETWORKS dat deze UBIQUITI NETWORKS device, voldoet aan de essentiële eisen en aan de overige relevante bepalingen van Richtlijn 1999/5/EC.

**English** Hereby, UBIQUITI NETWORKS, declares that this UBIQUITI NETWORKS device, is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

**Eesti [Estonian]** Käesolevaga kinnitab UBIQUITI NETWORKS seadme UBIQUITI NETWORKS device, vastavust direktiivi 1999/5/EÜ põhinõuetele ja nimetatud direktiivist tulenevatele teistele asjakohastele sätetele.

**Suomi [Finnish]** UBIQUITI NETWORKS vakuuttaa täten että UBIQUITI NETWORKS device, tyyppinen laite on direktiivin 1999/5/EY oleellisten vaatimusten ja sitä koskevien direktiivin muiden ehtojen mukainen.

**Français [French]** Par la présente UBIQUITI NETWORKS déclare que l'appareil UBIQUITI NETWORKS, device est conforme aux exigences essentielles et aux autres dispositions pertinentes de la directive 1999/5/CE.

**Deutsch [German]** Hiermit erklärt UBIQUITI NETWORKS, dass sich diese UBIQUITI NETWORKS device, in Übereinstimmung mit den grundlegenden Anforderungen und den anderen relevanten Vorschriften der Richtlinie 1999/5/EG befindet.“ (BMW i)

**Ελληνική [Greek]** ΜΕ ΤΗΝ ΠΑΡΟΥΣΑ UBIQUITI NETWORKS ΔΗΛΩΝΕΙ ΟΤΙ UBIQUITI NETWORKS device, ΣΥΜΜΟΡΦΩΝΕΤΑΙ ΠΡΟΣ ΤΙΣ ΟΥΣΙΩΔΕΙΣ ΑΠΑΙΤΗΣΕΙΣ ΚΑΙ ΤΙΣ ΛΟΙΠΕΣ ΣΧΕΤΙΚΕΣ ΔΙΑΤΑΞΕΙΣ ΤΗΣ ΟΔΗΓΙΑΣ 1995/5/ΕΚ.

**Magyar [Hungarian]** Alulírott, UBIQUITI NETWORKS nyilatkozom, hogy a UBIQUITI NETWORKS device, megfelel a vonatkozó alapvető követelményeknek és az 1999/5/EC irányelv egyéb előírásainak.

**Íslenska [Icelandic]** Hér með í sír UBIQUITI NETWORKS yfir ví a UBIQUITI NETWORKS device, er í samræmi við grunnkröfur og a rar kröfur, sem ger ar eru í tilskipun 1999/5/EC.

**Italiano [Italian]** Con la presente UBIQUITI NETWORKS dichiara che questo UBIQUITI NETWORKS device, è conforme ai requisiti essenziali ed alle altre disposizioni pertinenti stabilite dalla direttiva 1999/5/CE.

**Latviski [Latvian]** Ar o UBIQUITI NETWORKS deklar , ka UBIQUITI NETWORKS device, atbilst Direkt vas 1999/5/EK b tiskaj m pras b m un citiem ar to saist tajiem noteikumiem.

**Lietuviškai [Lithuanian]** UBIQUITI NETWORKS deklaruoja, kad šis UBIQUITI NETWORKS įrenginys atitinka esminius reikalavimus ir kitas 1999/5/EB Direktyvos nuostatas.

**Malti [Maltese]** Hawnhekk, UBIQUITI NETWORKS, jiddikjara li dan UBIQUITI NETWORKS device, jikkonforma mal- ti ijjiet essenzjali u ma provvedimenti o rajn relevanti li hemm fid-Dirrettiva 1999/5/EC.

**Norsk [Norwegian]** UBIQUITI NETWORKS erklærer herved at utstyret UBIQUITI NETWORKS device, er i samsvar med de grunnleggende krav og øvrige relevante krav i direktiv 1999/5/EF.

**Slovensky [Slovak]** UBIQUITI NETWORKS t mto vyhlasuje, e UBIQUITI NETWORKS device, sp a základné po iadavky a v etky príslu né ustanovenia Smernice 1999/5/ES.

**Svenska [Swedish]** Härmed intygar UBIQUITI NETWORKS att denna UBIQUITI NETWORKS device, står i överensstämmelse med de väsentliga egenskapskrav och övriga relevanta bestämmelser som framgår av direktiv 1999/5/EG.



**Español [Spanish]** Por medio de la presente UBIQUITI NETWORKS declara que el UBIQUITI NETWORKS device, cumple con los requisitos esenciales y cualesquiera otras disposiciones aplicables o exigibles de la Directiva 1999/5/CE.

**Polski [Polish]** Niniejszym, firma UBIQUITI NETWORKS o wiadcza, e produkt serii UBIQUITI NETWORKS device, spełnia zasadnicze wymagania i inne istotne postanowienia Dyrektywy 1999/5/EC.

**Português [Portuguese]** UBIQUITI NETWORKS declara que este UBIQUITI NETWORKS device, está conforme com os requisitos essenciais e outras disposições da Directiva 1999/5/CE.

**Română [Romanian]** Prin prezenta, UBIQUITI NETWORKS declară că acest dispozitiv UBIQUITI NETWORKS este în conformitate cu cerințele esențiale și alte prevederi relevante ale Directivei 1999/5/CE.

## mFi Products

Ubiquiti Networks offers a variety of products for the mFi platform. For additional details, visit [www.ubnt.com/mfi](http://www.ubnt.com/mfi)



Ceiling Mount  
Motion Sensor  
*mFi-MSC*



Wall Mount  
Motion Sensor  
*mFi-MSW*



Temperature  
Sensor  
*mFi-THS*



Current Sensor  
*mFi-CS*



Door Sensor  
*mFi-DS*



Thermostat  
*Coming Soon!*



mPort  
*mPort*



mPort Serial  
*mPort-S*



Power Adapter  
*mPower mini (EU)*



Power Strip  
*mPower (EU)*



Support **[support.ubnt.com](http://support.ubnt.com)**

Wiki Page **[wiki.ubnt.com](http://wiki.ubnt.com)**

Support Forum **[forum.ubnt.com](http://forum.ubnt.com)**

Downloads **[downloads.ubnt.com](http://downloads.ubnt.com)**

