





netis Wireless N Router Quick Installation Guide

1.Package Contents


*This QIG is for all netis 150Mbps/300Mbps wireless N routers, including models- WF2409, WF2409D, WF2411, WF2411D, WF2411I, WF2412, WF2412I, WF2414, WF2414D, WF2414I, WF2419, WF2419D, WF2419I, WF2420, WF2420I, WF2411E, WF2422E, WF2409E, etc.
* The product model shown in this QIG is WF2419I, as an example.



Wireless N Router



Power Adapter




Ethernet Cable



QIG

2.Hardware Connection



- Power off your Modem.
- Connect the **WAN** port on netis Router to the Modem's **LAN** port with an Ethernet cable.
- Connect your computer to one of the **LAN** ports on netis Router with an Ethernet cable.
- Power on your Modem.
- Plug the provided Power Adapter into the **PWR** jack of netis Router and the other end to a standard electrical socket. Then wait for one minute.

3.Configure the Router via Web Management Page

- Set the IP address of the wired network adapter on your computer as "Automatic" or "DHCP".

For Windows 8/7/Vista

- Go to "Settings" (Win 8)/ "Start" (Win 7/Vista) > "Control Panel".
- Left-click on "Network and Internet" > "Network and Sharing Center" > "Change adapter settings" (Win 8/7) / "Manage network connections" (Win Vista).
- Right-click on "Local Area Connection" and left-click on "Properties".
- Double-click on "Internet Protocol Version 4 (TCP/IPv4)".
- Select "Obtain an IP address automatically" and "Obtain DNS server address automatically" then left-click on "OK".

For Windows XP/2000

- Go to "Start" > "Control Panel".
- Left-click on "Network and Internet Connections" > "Network Connections".
- Right-click on "Local Area Connection" and left-click on "Properties".
- Double-click on "Internet Protocol (TCP/IP)".
- Select "Obtain an IP address automatically" and "Obtain DNS server address automatically" then left-click on "OK".

For MAC OS

- Click on the "Apple" menu > "System Preferences".
- Click on the "Network" icon.
- Click on "Ethernet" in the left side box and click on "Advanced" in the lower right corner.
- In the top options, select "TCP/IP".
- In the pull-down menu next to "Configure IPv4", select "Using DHCP".
- Click "OK" then "Apply".

- Open your browser and type **192.168.1.1** in the address field to visit router's web management page.

192.168.1.1

3. 3.

- In "Quick Setup" page, select your **Internet Connection Type**. If "DHCP (Cable Modem)" is selected, the router will automatically receive the IP parameters from your ISP (Internet Service Provider). If "Static IP" is selected, please enter the **IP Address/Subnet Mask/Default Gateway/DNS Servers** given by your ISP. If "PPPoE" is selected, please enter the **Username** and **Password** given by your ISP.
- Under **Wireless Setup**, configure your wireless network name (SSID) and password.
- Left-click on "Save" to make your settings take effect.




Tip 1:
Default IP address: 192.168.1.1
Default SSID: netis
Default wireless password: password

Tip 2:
You can click on button on the top for other Internet connection types and further settings.

4.Troubleshooting

- Q** How do I restore my netis Router's configuration to its default settings?
- A** With the router powered on, use a pin to press and hold the **Default** button on the rear panel for 8 to 10 seconds before releasing it. The router will reboot and all configurations are back to factory default.



- Q** What can I do if my Internet cannot be accessed?
- A**
- Check to verify the hardware connections are correct. Please refer to the "Hardware Connection" step.
 - Login to netis Router's web management page and ensure that you set the correct Internet Connection Type. For cable modem users, please configure "MAC Clone" additionally. On the left-side menu, left-click on > "Network" > "WAN". And in the middle page, left-click on "Advanced" > "MAC Clone" and then "Save" it.
 - Reboot the modem first and then netis Router. Wait for one minute before you check the Internet again.
 - If Internet access is not available, please connect your computer directly to your modem and try the Internet again. If the Internet is still not working, please contact your ISP for further help.

Appendix A: FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
—Reorient or relocate the receiving antenna.
—Increase the separation between the equipment and receiver.
—Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
—Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure Statement

This device complies with FCC radiation exposure limits set forth for an uncontrolled environment and it also complies with Part 15 of the FCC RF Rules. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Caution!
Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Appendix B: Industry Canada Statement (For WF2412, WF2409)

This Class B digital apparatus complies with Canadian ICES-003.
Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

This device complies with Industry Canada RSS-210. Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) This device must accept any interference, including interference that may cause undesired operation of the device.
Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio RSS-210. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

The device meets the exemption from the routine evaluation limits in section 2.5 of RSS 102 and compliance with RSS-102 RF exposure, users can obtain Canadian information on RF exposure and compliance.
Le dispositif rencontre l'exemption des limites courantes d'évaluation dans la section 2.5 de RSS 102 et la conformité à l'exposition de RSS-102 rf, utilisateurs peut obtenir l'information canadienne sur l'exposition et la conformité de rf.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20 centimeters between the radiator and your body.
Cet émetteur ne doit pas être Co-placé ou ne fonctionnant en même temps qu'aucune autre antenne ou émetteur. Cet équipement devrait être installé et actionné avec une distance minimum de 20 centimètres entre le radiateur et votre corps.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication. This radio transmitter (identify the device by certification number, or model number if Category II) has been approved by Industry Canada to operate with the antenna types listed below with the maximum permissible gain and required antenna impedance for each antenna type indicated. Antenna types not included in this list, having a gain greater than the maximum gain indicated for that type, are strictly prohibited for use with this device.

Technical Support:

USA/ Canada:
Toll Free: +1 866 71 network (+1 866 716 3896)
E-mail: usa_support@netis-systems.com

Other Regions:
E-mail: support@netis-systems.com

NETIS SYSTEMS CO., LTD.
www.netis-systems.com
MADE IN CHINA

PKUM05260

成品：86*124MM